



RTP 車縫輔助裝置安裝手冊  
THE INSTRUCTION GUIDE BOOK  
FOR RTF SUPPLEMENTARY DEVICE



安裝前,請詳細閱讀安裝說明書

PLEASE READ INSTRUCTIONS & ASSOCIATED DRAWINGS BEFORE INSTALLATION

# RTP 氣動型滾輪擴張裝置零件圖

Parts list for pneumatic roller tention device

RTP

